

Amigo

AMIGO EXTENSION ALUMINIUM WALLS TARPAULIN FLAT COVER ASSEMBLY INSTRUCTIONS

The tarpaulin flat cover set consists of:

- 1 tarpaulin flat cover
- 18 cord holders - grey
- 18 hammer head nuts M4
- 18 Philips round head screws M4 x 12



Place the round head screw through the cord holder and fit the hammer head nut on the round head screw.



Place the tarpaulin flat cover over the extension aluminium walls.



Fit three cord holders in the angled T-groove on the front and rear walls. Fit five cord holders in the angled T-groove on the left and right-hand side walls between the eyelets in the tarpaulin flat cover.

Make sure to rotate the hammer head nut 90° in the T-groove.



Pull the elastic cord over the cord holders.

Make sure the tarpaulin flat cover is pulled tightly over the trailer.



To fit the extension boards, see AMIGO EXTENSION ALUMINIUM WALLS ASSEMBLY INSTRUCTIONS. Net weight of the extension aluminium wall flat tarpaulin cover set: 4 kg