

# Amigo

## AMIGO TARPAULIN FLAT COVER ASSEMBLY INSTRUCTIONS

The tarpaulin flat cover set consists of:

- 1 tarpaulin flat cover
- 18 cord holders - grey
- 18 hammer head nuts M4
- 18 Philips round head screws M4 x 12



Place the round head screw through the cord holder and fit the hammer head nut on the round head screw.



Place the tarpaulin flat cover over the trailer.



Fit three cord holders in the T-groove on the front and rear walls. On the rear wall, place the cord holders between the lights. On the side wall, place two cord holders in the T-groove in front of the mudguard and two cord holders in the T-groove behind the mudguard between the eyelets in the tarpaulin flat cover. Make sure the hammer head nut is rotated 90° in the T-groove.



Pull the elastic cord over the cord holders.  
Make sure the tarpaulin flat cover is pulled tightly over the trailer.



Net weight of the tarpaulin flat cover set:  
4 kg