

# Amigo

## AMIGO PROP STAND ASSEMBLY INSTRUCTIONS

The prop stand set consists of:

- 2 prop stands
- 2 prop stand supports
- 4 hammer head bolts M8 x 20
- 4 flange nuts M8



Unscrew the handle out of the clip fastener.

Fit two hammer head bolts in the T-groove on the outside of the trailer at the front, on the left-hand side or on the right-hand side, and rotate the hammer head bolt 90°.



Fit the prop stand support over the two hammer head bolts. Screw a flange nut on each hammer headbolt and use a 13 mm open-ended spanner to tighten the flange nuts.



Place the prop stand in the support and securely tighten the handle.



When you have connected the trailer to the back of your car, make sure the prop stand is raised.



Net weight of the prop stand set: 6 kg