

Amigo

AMIGO SPARE WHEEL ASSEMBLY INSTRUCTIONS

The spare wheel set consists of:

- 1 spare wheel
- 1 spare wheel bracket
- 2 washers M10
- 2 lock nuts M10



Place the spare wheel bracket over the drawbar under the trailer. This can be either in front of or behind the axle. Pay attention to how you load the trailer.



Place the spare wheel under the bracket.



Lift the spare wheel over the bracket's two stud bolts.



First, fit the washer on the stud bolt and then the lock nut.



Use a 17 mm open-ended spanner to firmly tighten the lock nuts. Make sure the walls of the tyre are pushed against the bottom of the drawbar.



Tyre pressure: 2.8 bar (41 PSI)
Check the tyre pressure each month.
Net weight of the spare wheel set: 12 kg